### Los Alamos National Laboratory Engineering and Design Support for Commercial U.S. Electron Accelerator Production of <sup>99</sup>Mo

Gregory E. Dale, Keith A. Woloshun, Michael Holloway, Charles T. Kelsey IV, Michael Mocko, Eric R. Olivas, Frank P. Romero, and Dale A. Dalmas

Los Alamos National Laboratory, P.O. Box 1663, Los Alamos, NM 87545 - USA

and

J.T. Harvey

NorthStar Medical Technologies, LLC, 5249 Femrite Drive, Madison, WI 53718








## Proof of Concept Demonstrations for Electron Accelerator Production of <sup>99</sup>Mo

- Under the direction of the NNSA, LANL and ANL are partnering with NorthStar Medical Technologies to demonstrate and develop accelerator production of <sup>99</sup>Mo through the <sup>100</sup>Mo(γ,n)<sup>99</sup>Mo reaction.
  - The threshold for the reaction is 9 MeV.
  - The peak cross section is 150 mb at 14.5 MeV.
- High energy photons are created with a high power electron beam through bremsstrahlung.









#### Scaled Accelerator Tests at Argonne National Laboratory

 To date, five accelerator tests have been performed using the electron accelerator at ANL.

Date	Test
April 2010	Water-cooled target test using natural Mo targets, produced 236 µCi of <sup>99</sup> Mo.
May 2010	Water-cooled target test using natural Mo targets, produced 377 µCi of 99Mo.
July 2010	Water-cooled production test using enriched <sup>100</sup> Mo targets, produced 10.5 mCi of <sup>99</sup> Mo.
April 2011	Once through gaseous helium-cooled thermal test using natural Mo targets, 145 µCi of <sup>99</sup> Mo.
March 2012	Closed loop gaseous helium thermal test using natural Mo targets.










### **Closed Loop Gaseous Helium Cooling System Layout**










# **Gaseous Helium Flow Loop Using a Roots Blower**

The roots blower is used to move the He through the loop and across the targets. The PV is used to increase the base pressure of the system to 300 psi.

Pressure Vessel (PV)












#### **Helium Gas Cooled Thermal Test**

- Performed on March 27, 2012.
- Operated up to a peak beam power of 12 kW at 15 MeV with a 6 mm
   FWHM beam.
- Achieved a production relevant peak heat flux of 819 W/cm².










#### FY12 Target and Vacuum Cube Assembly Design

For the FY12-FY13 accelerator tests, we have integrated the target design into the vacuum system.

#### Exploded view

2x 304 S.S. Pipe Extenders




18-8 S.S. Dowel Pin

Alloy 718 Target Disk Holder

Alloy 718 Housing

#### Cut-away view




The target is axially symmetric for twosided irradiation.







## <sup>99</sup>Mo Production Density With and Without an X-Ray Converter. Cylindrical Target, plotted vs. R and Z











## Target Heating With and Without an X-Ray Converter. Cylindrical Target, plotted vs. R and Z



















#### **CFD Modeling Results of the Target for the Thermal Test**



Cooling gas temperature

Cooling gas velocity in each channel











## CFD Analysis of the Target Temperature for the Thermal Test



Temperature plot of the target assembly and housing for 15 MeV and 1170 µA (17.6 kW)

Peak temperature of the front window, target assembly, and back window for 15 MeV and 1170 µA (17.6 kW)










### Disk Thermocouple Data 12 kW beam, 270 psi, 25 psi ΔP, 100 g/sec










### IR Camera for Target Window Temperature Measurement

- The target window is the most highly stressed component of the design.
- An infrared (IR) camera system has been developed to monitor the front window temperature during irradiation.
- The IR system complements the optical transition radiation (OTR) system used to measure the beam spot size and profile during the irradiation.



IR image of a test coupon used at LANL to calibrate the camera










## Mock up and flow test of the target section using particle image velocimetry (PIV)









#### **Future Work**

- Planning to perform a thermal test of the target using the upgraded ANL electron accelerator. Two sided irradiation will be demonstrated during this next thermal test.
- The thermal test will be followed by a production test using enriched <sup>100</sup>Mo targets.
- Planning on more production tests over the summer to test multiple batches of enriched <sup>100</sup>Mo targets.
- Working with Mevex, the accelerator supplier for the production facility, to install a closed-loop helium cooling system at their facility. This has begun the process of integrating the target cooling system design into the production accelerator system. Planning on a summer thermal test at Mevex to test the system at production relevant heat fluxes.





