

A Technical Demonstration of the Initial Stage of Mo-99 Recovery from a Low Enriched Uranium Sulfate Solution

A.S. Anderson, L.J. Bitteker, R. Copping, G.E. Dale, D.A. Dalmas, M.J. Gallegos, E. Garcia, C.T. Kelsey IV, I. May, S.D. Reilly, D. Rios, F.H. Stephens, F.L. Taw and K. Woloshun

*Science, Technology and Engineering
Los Alamos National Laboratory, P.O. Box 1663,
Los Alamos, NM 87545, US*

**Funding: - National Nuclear Security Administration's
Global Threat Reduction Initiative**

Previous LANL Based Separation Chemistry Research in Support of SHINE Medical Technologies Inc.

- Experimental work started January 2011
- Focus on the initial separation and recovery of Mo-99 from aqueous uranium solutions – the target for particle accelerator produced Mo-99
- Multiple LEU Sample Irradiations
 - Evolving sample containment and sample irradiation capability
 - Demonstrated that Mo-99 can be recovered in > 90% yield from irradiated uranium solutions using titania as a sorbent
 - Demonstrated that Mo-99 can be recovered from both irradiated uranium sulfate and nitrate solutions
 - Uranium sulfate - potential operational advantages vs. uranium nitrate fuel

Dale, G.E., Dalmas, D.A., Gallegos, M.J., Jackman, K.R., Kelsey, C.T., May, I., Reilly, S.D., Stange, G.M., “Mo-99 Separation from High Concentration Irradiated Uranium Nitrate and Uranium Sulfate Solutions.” Ind. Eng. Chem. Res. (2012) 51:13319-13322.

Technical Challenge


- **Confirm high % Mo-99 recovery from irradiated uranyl sulfate using a direct downscale of a titania column recovery process that could be used in plant operations**
- **Confirm the fuel recycle concept – irradiated uranyl sulfate can be recycled with no loss in % Mo-99 recovery**
- ***Requires design of new sample containers for containment of greater volumes of solution (up to 150 mL)***
- ***Requires access to a new capability for sourcing neutrons at LANSCE (Target 4)***
- ***Requires new procedures for LEU uranium and irradiated sample chemical manipulations***
- ***Requires the development of semi-automated column separation apparatus that can ultimately be used in a hot cell***

Uranium Sulfate Fuel Preparation

- Started with 19.5 % ^{235}U enriched uranium nitrate solution
- Converted to uranium sulfate solution using standard inorganic chemical procedures
 - removing all the nitrate a non-trivial task
- Final uranium fuel concentration – aimed for 150 gU/L (0.63 mol/L)
 - 150.4 gU/L using ‘in house’ developed spectroscopic technique
 - 150.3 gU/L by Davies-Gray titration
- Prior to sample irradiation fuel spiked with aqueous solution of Na_2MoO_4 (sodium molybdate) to more accurately reflect Mo-99 production concentration


Technique development – major contribution from University of Wisconsin summer students Gary Stange and Alex Schroeder

Sample Containment for Irradiation



Target 4 – Capability Development

- New irradiations capability at LANSCE
- “90 Up” flight path
- 10^9 n/cm²/sec thermal neutron flux
- Performed 3 sample irradiations and Mo-99 separation chemistry between December 2012 and January 2013
- Shipped solutions to TA-48 for separation chemistry experiments



Target 4 – Capability Development



Irradiated Sample – Gas Collection for Later Analysis

- Samples degassed (freeze-pump-thaw) before irradiation to minimize background from air
- Irradiated samples placed under argon atmosphere (~600 Torr)
- After irradiation, head space gas (~60 cc) expanded into evacuated cylinder (500 cc) and stored to decay
- Analysis by mass spectrometry in progress (H_2 & O_2)




Irradiated LEU Solutions – Experimental Details

Experimental Details	1 st Irradiation	2 nd Irradiation	3 rd Irradiation
Irradiation date	11 th Dec. '12	9 th Jan. '13	28 th Jan. '13
Uranium conc. (mol/L)	0.63	0.65	0.64
Solution density (g/mL)	1.19	1.20	1.21
% recycle irradiated uranium	0 %	78 %	77 %
pH before irradiation	1.0	1.2	1.1
pH after irradiation	1.1	1.2	1.2
Mo-99 production (μCi)	1000	900	1100


DIRECT DOWNSCALE OF SHINE COLUMN PROCESS

- **Titania column designed to separate Mo-99 from the vast excess of LEU in dilute sulfuric acid solution**
 - Mo-99 product for further downstream processing
 - LEU product for potential recycle
- **Input parameters provided by D. Stepinski, M. Youker & G. Vandegrift at ANL**
 - Based on experimental work and VERSE code simulation
- **Experimental set-up designed by F. Stephens at LANL**
 - Initially designed for fume hood work (TARGET 4 irradiated samples)
 - Must be compatible with hot cell operations
 - Only minor experimental modifications of original input parameters

Schematic of Column Separation



Column Separation Apparatus




Column and post-experiment titania resin

Direct Downscale Demonstration of Mo-99 Recovery using Titania Column


Titania column separation	1 st Irradiation	2 nd Irradiation	3 rd Irradiation
Volume of LEU sulfate feed (mL)	129	128	136
Volume of NaOH strip required for > 95 % Mo-99 recovery (mL)	9.3	9.7	22.3
Mo-99 activity balance (%)	97	102	95

High volume of NaOH strip in 3rd irradiation column separation – attributed to process development for hot cell operation


Titania Separation – Fraction analysis




Titania Separation – Fraction analysis



Titania Separation – Fraction analysis



Titania Separation – Fraction analysis




Summary

- **New sample irradiation capability (Target 4) and sample containment methods developed**
- **Well characterized LEU uranyl sulfate fuel prepared**
- **Fume hood and hot cell compatible separations apparatus developed for downscale testing of titania column recovery of fission Mo-99**
- **Near quantitative recovery of Mo-99 achieved from irradiated LEU uranium sulfate solutions**
- **Recycling irradiated LEU uranyl sulfate solutions has no impact on Mo-99 recovery using titania**


Previous Batch Distribution Experiments – Jan. 2012

Irradiated uranyl nitrate (UN) and uranyl sulfate (US)



Uranium Sulfate Fuel Preparation


Raman spectra – monitor nitrate removal from sulfate fuel



Technique development – major contribution from
University of Wisconsin summer student Gary Stange

Uranium Sulfate Fuel Preparation

UV/Vis technique - determination of uranium concentration



**Technique development – major contribution from
University of Wisconsin summer student Alex Schroeder**

UNCLASSIFIED

Slide 21

Sample Containment

- **Stainless steel outer and inner containers - design provides for double containment of the solution**
- **The outer bottle is designed to fit within a Viking container for transportation to TA-48**
- **Outer bottle also filled with 500 mL of water for neutron moderation and a little bit of fission energy absorption.**
- **EPDM (ethylene propylene diene monomer) o-ring on the outer bottle lid, 100-200 kGy tolerance.**
- **UHMWPE (Ultra-high-molecular-weight polyethylene) in the valve packing, 1,000 kGy tolerance.**
- **Inner bottle design pressure is 150 psi & outer bottle design pressure is 25 psi**

**Tolerance levels from the Nordion Gamma
Compatible Materials Reference Guide.**

Titania Column Separation

- More detailed analysis of Mo-99 base fractions on going (e.g. activities of longer lived radioisotopes such as Ru-103)
- Major contaminants in recycled uranium included Ru-103, I-131, Ba-140, La-140 & Ce-143
- Major contaminants irreversibly bound to the resin included Zr-95/97 and Te-132

Preliminary I-131 Speciation Results (3rd Irradiation)

Sample	IO ₃ ⁻ (%)	I ₂ (%)	I ⁻ (%)	Activity balance (%)
Irradiated solution (3 days after EOB)	48	16	36	76
Irradiated solution (8 days after EOB)	40	23	37	65
Column fraction 2 (irradiated uranium)	25	60	15	70
Column fraction 7 (pH 2.77)	5	67	28	69
Column fraction 9 (11.65)	0	13	87	75