

Separation, Purification, and Clean-Up Developments for MIPS and SHINE

Argonne National Laboratory
Mo-99 Topical Meeting
Santa Fe, New Mexico
December 4 – 7, 2011


MIPS and SHINE

- Argonne is assisting 2 potential domestic suppliers
- Babcock and Wilcox Technical Services Group (BWTSG) – Medical Isotope Production System (MIPS)
- Morgridge Institute for Research (MIR) – Subcritical Hybrid Intense Neutron Emitter (SHINE)
- Pure titania sorbent to separate Mo-99 from uranyl nitrate and uranyl sulfate solutions
- LEU-Modified Cintichem process is being considered for Mo purification




Mo-99 Separation

- S110 (pure titania sorbent) is the top candidate for Mo-99 separation and recovery column
- S110 replaces S80 which has been discontinued
- S110 outperforms S80
- Plant-scale column has been designed for BWTSG
- Plant-scale column design will be available for MIR in ~ 1 week
- Mo-99 recovery continuously being optimized
- Oxidizing agents have been added to water wash and strip solutions to help improve Mo-99 recovery





From Batch to Column...



- Batch data input into VERSE (Versatile Reaction Separation) simulator
- Data specific to VERSE code for column design
- Langmuir-type adsorption via batch contact experiments
- No breakthrough column tests
- Preliminary plant-scale column design
- Small-scale column tests
- Modified plant-scale column design



Langmuir Data for Uranyl Sulfate



- Batch data fit to Langmuir model for 150 and 90 g-U/L uranyl sulfate solutions
- Langmuir data in batch mode yields a good estimate of “a” linear parameter for Langmuir model
- Data used to predict conditions for Mo breakthrough curve experiments
- Mo breakthrough column tests give a good estimate of “b” non-linear parameter for Langmuir model

$$q_i = \frac{a_i \cdot C_i}{1 + b_i \cdot C_i}$$




Mo Breakthrough Column Designs – 90 g-U/L

Sorbent	ID (cm)	L (cm)	CV (mL)	u_s/L (min ⁻¹)	u_s (cm/min)	Mo amount *(meq/CV)	ΔP (atm)	Flowrate (mL/min)	To achieve a complete breakthrough curve	
									Time (hr)	Volume* (mL)
S110	0.66	1	0.34	3	3	0.0032	0.01	1.0	> 10	> 616
S110	0.66	1	0.34	4	4	0.0032	0.01	1.4	10	821
S110	0.66	1	0.34	5	5	0.0032	0.01	1.7	10	1026
S110	1.0	1	0.8	3	3	0.0074	0.01	2.4	> 10	> 1414
S110	1.0	1	0.8	4	4	0.0074	0.01	3.1	10	1885
S110	1.0	1	0.8	5	5	0.0074	0.01	3.9	10	2356
S110	1.0	1.5	1.2	3	4.5	0.0111	0.01	3.5	> 10	> 2121
S110	1.0	1.5	1.2	4	6.0	0.0111	0.02	4.7	10	2827
S110	1.0	1.5	1.2	5	7.5	0.0111	0.02	5.9	10	3534
S110	1.0	2.0	1.6	3	6	0.0148	0.02	4.7	> 10	> 2827
S110	1.0	2.0	1.6	4	8	0.0148	0.03	6.3	10	3770
S110	1.0	2.0	1.6	5	10	0.0148	0.04	7.9	10	4712

- 0.045 mM Mo - ~20X higher than actual Mo concentration expected
- Lower Mo concentration may take 15 – 20 hours to achieve full Mo breakthrough with S110
- Loading velocities range from 3 – 10 cm/min
- Experiments have been completed with 0.66 cm ID x 1 cm L and 1 cm ID x 1 cm L S110 columns




VERSE Mo Breakthrough Simulations - 90 g-U/L



- Mo breakthrough curve simulations
- Loading velocities for 3, 4, and 5 cm/min with a column length of 1 cm
- Breakthrough occurs earlier when loading velocity is increased
- 0.66 cm ID x 1 cm L S110 column




0.66 cm ID x 1 cm L Results



- VERSE predicted full Mo breakthrough achieved after >616, 821, and 1026 mL are passed through column at 3, 4, and 5 cm/min
- S110 performs better than expected based on VERSE predictions
- Mo breakthrough is not achieved after 980 mL at 3 cm/min and 1330 mL at 4 cm/min are passed through the column
- Full Mo breakthrough achieved after 1750 mL of solution are passed through the column at 5 cm/min

1 cm ID x 1 cm L Results



- VERSE predicted full Mo breakthrough would occur after >1414, 1885, 2356 mL are passed through the column at 3, 4, and 5 cm/min
- Mo breakthrough is not achieved after 2100 mL at 3 cm/min and 2247 mL at 4 cm/min are loaded onto the column
- Mo surprisingly begins to breakthrough more rapidly at 3 cm/min rather than at 4 cm/min
- Full Mo breakthrough achieved after 3500 mL of solution are passed through the column at 5 cm/min


Mo-99 Separation Updates for Uranyl Nitrate

Date of Run	Column Size (ID x L)	Velocity (cm/min)	Sorbent	%Mo in Effluent	%Mo in Washes	%Mo Recovered	Stripping Agent
09/15/11	1.5 x 3.1	9	S40	16.0	0.6	86.0	1 M NH ₄ OH
09/21/11	1.5 x 6.2	3	S110	1.0	0.6	88.0	1 M NH ₄ OH
09/23/11	1.5 x 6.3	5	S110	1.0	1.0	85.0	1 M NH ₄ OH
09/26/11	1.5 x 2.6	5	S40	32.0	0.3	80.0	1 M NH ₄ OH
09/28/11	1.5 x 6.3	10	S110	1.0	0.1	77.0	1 M NH ₄ OH
09/30/11	1.5 x 6.3	7.5	S110	2.0	0.1	85.0	1 M NH ₄ OH
10/06/11	1.5 x 6.2	7.5	S110	7.3	0.8	73.0*	1 M NH ₄ OH
10/12/11	1.5 x 6.2	3	S110	7.0	1.0	89.0*	1 M NH ₄ OH


- Feed solution ~150 g-U/L uranyl nitrate, stable Mo, and Mo-99
- Column tests performed with S40 and S110 with 60 Å pores
- S110 outperforms S40 which had a significant amount of Mo in effluent
- Mo recoveries varied from 73 – 89%
- Stripping velocity had little effect on Mo recovery
- 0.5 wt.% KMnO₄ added to first water wash for runs on 10/06 and 10/12

S110 vs. S80 for Mo Breakthrough

S110 Mo Breakthrough Results



S80 Mo Breakthrough Results



- 1 cm ID x 1.6 cm L column with a linear velocity of 13 cm/min
- 5 L for S110 compared to 3 L for S80 for almost full Mo breakthrough to occur
- Mo breakthrough occurs more rapidly with S110 compared to S80
- Current plant-scale column designs for uranyl nitrate solutions using S80 should work for S110

Effects of Temperature

Sorbent	Solution	K_d , Mo, (mL/g) 20°C	K_d , Mo, (mL/g) 40°C	K_d , Mo, (mL/g) 60°C
S110	90 g-U/L uranyl sulfate	2600	3500	6200
S110	150 g-U/L uranyl nitrate	7000	12000	21000



- Batch studies performed as a function of temperature after 24 hours of contact
- K_d values ~2X higher for sulfate and 3X higher for nitrate in going from 20-60°C
- Solution is not heated prior to column loading due to heat loss in the pump
- Temperature of solution entering column is not 60°C but column is kept at 60°C
- Stainless steel coils wrapped in heat tape were added before and after the column
- Mo adsorption is significantly affected by temperature
- If temperature is controlled better, more Mo may adsorb
- 2 – 5% Mo typically observed in effluent
- VERSE column sizes are designed to be able to adsorb at least 2X more Mo than needed



Mo-99 Separation Wrap-Up

- S110 can be used to separate Mo-99 from LEU uranyl nitrate or uranyl sulfate solutions
- Current plant-scale column designs for BWTSG using S80 will work for S110 as well
- Plant-scale column designs are almost complete for MIR
- Recovery of Mo-99 continuously being optimized
- Small-scale column experiments will be done for MIR when plant-scale design is complete
- Mini-MIPS/SHINE experiments will provide useful data regarding the fate of other fission products in the separation, recovery, and purification processes



Radiolytic Stability of Mo-ABO Precipitate



- Precipitation of Mo with alpha-benzoin oxime is an important step in Cintichem purification process
- Mo yields unaffected when up to 1000 Ci of Mo-99 was processed in a single Cintichem run
- If production yields are higher, primary concern is that ABO will radiolytically breakdown and Mo yields will decrease
- Several 6-day kCi per batch are expected for processing
- Van de Graaff (VDG) accelerator was used to irradiate the Mo-ABO precipitate at doses equivalent to ~160 kCi of Mo-99
- Stability of the precipitate was examined after irradiation

ABO Irradiation at Van de Graaff

Mo carrier
and KMnO_4 to
 $\sim 1.4\text{M HNO}_3$

ABO precipitate,
centrifug., wash
 0.1M HNO_3

Dissolution
 0.4M ; 0.2M
 $\text{NaOH}/1\%\text{H}_2\text{O}_2$

- ABO precipitate
- Centrifuge, discard solution
- Irradiate (0.1 M HNO_3)
- Transfer to filter vial
- Wash with 0.1 M HNO_3
- Centrifuge
- Dissolve in $0.4\text{ M NaOH}/1\%\text{H}_2\text{O}_2$
- Centrifuge
- Dissolve in $0.2\text{ M NaOH}/1\%\text{H}_2\text{O}_2$
- Centrifuge
- Rinse with 0.2 M NaOH
- Count filter, HNO_3 , NaOH fraction





Before irradiation
(24.4GRad)



After irradiation





MCNPX Simulations and Mo Recovery Results



MCNPX calculations

20 minutes (Cintichem process) is eq.
~62.5 MRad/ 1 kCi of ⁹⁹Mo

If modeled as a single layer ABO **~150 MRad per 1 kCi of Mo-99**
 (more conservative)



Four Potential Clean-Up Methods, If Required

- Methods listed below assume a uranyl sulfate solution
 1. Anion Exchange of uranyl sulfate complexes
 2. Direct Solvent-Extraction Process for Uranyl Sulfate
 3. Precipitation of Uranyl Ion as Uranyl Peroxide
 4. Conversion to nitrate media followed by UREX processing



Least Favorable Options for Clean-Up

- Anion exchange of uranyl sulfate complexes will not work because of the low capacity of the resins (1-2 meq/g and ~500 kg of resin for 200 L at 150 g-U/L)
- Direct solvent-extraction process for uranyl sulfate could work but the concentrations of trioctyl ammonium sulfate (TOA) and trioctyl phosphate (TOPO) and stripping conditions need to be determined
- Precipitation of uranyl ion as uranyl peroxide is problematic because it cannot be filtered or centrifuged
- The last two options could work but both would require a significant amount of R&D



Conversion to Nitrate Media Followed by UREX

- Steps
 - Addition of $\text{Ca}(\text{NO}_3)_2$ dissolved in 1 M HNO_3 to the irradiated uranyl sulfate solution in a stirred vessel; addition rate, stirring speed, and temperature must be set to optimize the morphology and size of the crystals formed to allow facile filtration
 - Passing the slurry into a filtration system to collect and wash the precipitate
 - UREX processing of the filtrate
 - Precipitation of uranium as ammonium diuranate and its filtration
 - Conversion of uranium to UO_3
 - Dissolution of UO_3 in sulfuric acid
 - Reconstitution to the uranyl-sulfate/0.1 M-sulfuric-acid target solution
 - Potential recycle of uranium from ammonium diuranate filtrate
 - Treatment of waste streams generated for storage and final disposal
- All process steps are used commercially and well understood
 - Minimum R&D is required to design processing facility



Concluding Remarks

- S110 will be used for Mo-99 separation and recovery columns for MIPS and SHINE
- Column stripping and loading conditions will continue to be optimized
- Future irradiations will take place at Argonne using the linac (mini-MIPS/SHINE experiments)
- Mo-ABO radiolytic stability tests show that ~10 kCi Mo-99 can be purified via the Cintichem process without losses due to ABO degradation
- If solutions need to be cleaned up, conversion to nitrate followed by UREX processing is the best option




Acknowledgements

Work supported by the U.S. Department of Energy, National Nuclear Security Administration's (NNSA's) Office of Defense Nuclear Nonproliferation, under Contract DE-AC02-06CH11357. Argonne National Laboratory is operated for the U.S. Department of Energy by UChicago Argonne, LLC.



Modified LEU-Modified Cintichem Process



- Mo product in 1 M NH₄OH used directly from column run
- It is evaporated to dryness using a rotary evaporator
- Precipitate is re-dissolved in 1 M HNO₃
- Additional steps were added to remove iodine
- Mo product in 1 M NaOH adds additional complications to the Cintichem purification process
 - Because the solution can not be evaporated, the feed volume to the process would be much too large