

Zircaloy-4 for Low-Temperature Use with Hydrogen and Neutron Exposure

Lauren Garrison

Chinthaka Silva

Mo-99 Topical Meeting 2018

SHINE solution vessel

ORNL supports SHINE with materials research for the target solution vessel and support pipes

Conditions of the Target Solution Vessel:

- Neutron irradiation
- Hydrogen exposure
- Water exposure
- Uranyl sulfate solution corrosion
- Temperature $<100^{\circ}\text{C}$
- Low pressure

Initially, several materials were surveyed:

- Stainless steels
- Zr2.5Nb
- Zircaloy-4





Image courtesy of SHINE <http://shinemed.com/demonstrated-technology/>

Zircaloy-4 Investigation


- Zircaloy-4 has a long history in the nuclear industry, but typically is used as cladding, ~200-400°C
- Considerations for SHINE target solution vessel:
 - Neutron irradiation
 - <100 °C
 - Hydrogen, water, uranium solution
 - Welding
- Additional data is needed to confidently use this material for the unique application and to satisfy the NRC for licensing of the facility

Preparation of Material

Zircaloy-4 material



Machined bars for welding tests




Tungsten Inert Gas Welding

- Welding tests performed at Major Tool & Machine Inc.
- ORNL developed a weld quality analysis procedure

Back of root pass



Cover pass 1



Final cover pass




Burn through on the root side




Post-weld heat treatment-Motivation

- **Base metal** total elongation is **~22-29%**
- **After TIG welding**, no post-weld heat treatment, total elongation is **similar to base metal for asymmetric samples** (one tab was in the weld and one tab reached the base metal)
- **After TIG welding**, no post-weld heat treatment, total elongation is **~10-13%** for symmetric weld samples



Zircaloy-4 Phases




“Reactor grade zirconium.” Technical Data Sheet. ATI (2015)

https://www.atimetals.com/Products/Documents/datasheets/zirconium/allo y/Zr_nuke_waste_disposal_v1.pdf#search=zircaloy-4

Zircaloy-4 Phases

- How weld affects phases and properties
- Ultimate tensile strength decreases
- Yield strength increases
- Total elongation decreases significantly



C.L. Whitmarsh, Review of Zircaloy-2 and Zircaloy-4 properties relevant to N.S. Savannah reactor design, Oak Ridge National Laboratory, ORNL-3281, (1962)


Quench

- Locks in some beta phase

Weld (melt)

Zircaloy-4 Phases

- Annealing affects corrosion and mechanical properties




899-1010°C annealing

- Forms significant beta phase
- 20-80% increased corrosion in 350°C water or 750°C steam
- Tensile total elongation reduced

C.L. Whitmarsh, Review of Zircaloy-2 and Zircaloy-4 properties relevant to N.S. Savannah reactor design, Oak Ridge National Laboratory, ORNL-3281, (1962)

Zircaloy-4 Phases

- Annealing affects corrosion and mechanical properties



Annealing below ~800°C


- Stays in alpha phase
- No change to corrosion rate
- Tensile properties can be improved

C.L. Whitmarsh, Review of Zircaloy-2 and Zircaloy-4 properties relevant to N.S. Savannah reactor design, Oak Ridge National Laboratory, ORNL-3281, (1962)

Post Weld Heat Treatment

Heat treatment parameters for Zry-4, weld-6 samples. **Holding time 1h.**

Sample	Target temperature (°C)	Ramping	Cooling
6-1	500	500 °C in 4.5 hours	Furnace cooling
6-2	600	600 °C in 5.0 hours	Furnace cooling
6-3	700	700 °C in 7.0 hours	Furnace cooling
6-4	750	750 °C in 7.0 hours	Furnace cooling
6-5	800	800 °C in 7.0 hours	Furnace cooling



C. M. Silva, C. D. Bryan. "Evaluation of Zircaloy-4 as the structural material for the Target Solution Vessel and support lines of SHINE — Sample preparation for the third-round neutron irradiation" FY17 Report. ORNL/TM-2017/482

Post Weld Heat Treatment

Heat treatment parameters for Zry-4, weld-6 samples. **Holding time 1h.**

Sample name	Cut location	PWHT temp. (°C)	Layer from surface	Ultimate tensile strength (MPa)	Yield stress (MPa)	Total elongation* (%)
ZFA01	SW	500	1	571	442	18.5
ZFA02	SW		2	583	468	19.4
ZFA03	SW		3	586	468	19.3
Average	SW		580		459	19
ZFB01	SW	600	1	601	488	17.7
ZFB02	SW		2	597	489	15.9
ZFB03	SW		3	586	476	15.6
Average	SW		595		484	16
ZFC01	SW	700	1	611	504	20.3
ZFC02	SW		2	596	485	17.1
ZFC03	SW		3	589	480	20.6
Average	SW		599		490	19
ZFD01	SW	750	1	568	477	17
ZFD02	SW		2	583	485	16.2
ZFD03	SW		3	583	481	20.9
Average	SW		578		481	18
ZFE01	SW	800	1	578	473	21.5
ZFE02	SW		2	592	482	20.9
ZFE03	SW		3	583	481	19.7
Average	SW		584		479	21

600°C slightly lower elongation

800°C slightly higher elongation

*TE values are overestimated here from raw data

Post Weld Heat Treatment

Heat treatment parameters for Zry-4, weld-7 samples. 800 °C, varied holding times.

Sample	Layer from surface	Ultimate tensile strength (MPa)	Yield stress (MPa)	Total elongation (%)	
ZGA01, 800C, 12h	1st of 4	588	487	18.1	consistent
ZGA02, 800C, 12h	2nd of 4	582	489	16.6	
ZGA03, 800C, 12h	3rd of 4	584	476	17.2	
ZGA04, 800C, 12h	4th of 4	572	474	17.2	
Avg.		582	482	17.2	
ZGB01, 800C, 24h	1st of 4	581	368	23.6	erratic
ZGB02, 800C, 24h	2nd of 4	495	428	9.1	
ZGB03, 800C, 24h	3rd of 4	553	485	12.9	
ZGB04, 800C, 24h	4th of 4	466	425	8.7	
Avg.		524	427	13.6	
ZGC01, 800C, 48h	1st of 4	351	346	17.8	erratic
ZGC02, 800C, 48h	2nd of 4	366	358	10.9	
ZGC03, 800C, 48h	3rd of 4	352	350	13.7	
ZGC04, 800C, 48h	4th of 4	495	434	13.4	
Avg.		391	372	14.0	

consistent Large elongation

erratic Smaller elongation than no post weld heat treatment


*TE values are overestimated here from raw data

Large grain growth likely caused spread in tensile data for long hold 800C treatments

- **ZGB2, 9.1 % elongation**



Typical grain structure



Large grain boundary-free area corresponded to fracture location

- Long holds at 800°C cause large grain growth and scatter in tensile elongation
- Similar recoveries were measured for test temperatures below 800°C
- Future post weld heat treatments will be below 800°C

Hydrogen in Zircaloy-4

- The most significant source of H in reactors is from water corrosion



- Radiolysis of water can also be a source

Zircaloy-4 has less H absorption than Zircaloy-2


- Zircaloy-2 (Grade R60802)

- Zr
- 1.5%Sn
- 0.15%Fe
- 0.1%Cr
- 0.05%Ni

Responsible for significant H absorption

- Zircaloy-4

- Zr
- 1.5%Sn
- 0.2%Fe
- 0.1%Cr



C.L. Whitmarsh, Review of Zircaloy-2 and Zircaloy-4 properties relevant to N.S. Savannah reactor design, Oak Ridge National Laboratory, ORNL-3281, (1962)

“Reactor grade zirconium.” Technical Data Sheet. ATI (2015)
https://www.atimetals.com/Products/Documents/datasheets/zirconium/alloy/Zr_nuke_waste_disposal_v1.pdf#search=zircaloy-4

Hydrogen effect on mechanical properties

- Hydrogen absorption in Zircaloy is expected to reduce the ductility
- Historical data for Zircaloy-2 shows severe effect above ~100 ppm H
- This must be tested for Zircaloy-4 under low temperature neutron irradiation

UNCLASSIFIED
ORNL-LR-DWG 56360

REF: CRMet-849, p 50, Fig. 17





Fig. 10. Effect of Hydrogen on Elongation of Zircaloy-2.

C.L. Whitmarsh, Review of Zircaloy-2 and Zircaloy-4 properties relevant to N.S. Savannah reactor design, Oak Ridge National Laboratory, ORNL-3281, (1962)

Hydrogen Charging



- Controlled hydrogen charging is accomplished with heating TiH_2 powder in a sealed vacuum tube with Zircaloy-4 samples present
- Samples with different ppm amounts are being produced now for inclusion in the neutron irradiation capsules

Neutron Irradiation of Zircaloy-4


- Samples are being prepared for neutron irradiation in HFIR at temperatures of 60 and 100°C and fluences of 1×10^{20} and 1×10^{21} n/cm² (E>0.1 MeV)

Testing plan for irradiated samples

- Tensile tests at room temperature
- Microhardness
- Microstructure




This style used to achieve ~100°C irradiation for this project




This style used to achieve ~60°C irradiation for this project

Rabbits inside target rod holder

Sub-size specimens for in-reactor irradiation





- Cannot fit in HFIR irradiation capsules
- Would have very high activity level after irradiation
- Cannot be used.



- Size and dose are significantly reduced with SS-3 samples
- End tabs used for microhardness measurements and microstructure characterization.




M.N. Gussev et al. / Nuclear Engineering and Design 320 (2017) 298–308



For certain applications, even smaller tensile samples can be used for neutron irradiated tests.

Overview of IMET

- Six interconnected steel-lined examination cells containing 30 m² of workspace.
- Cells 1~3 focusing on mechanical testing
- Low alpha contamination facility (<70 dpm / 100 cm²).
- Irradiation capsule disassembly, mechanical testing (tensile, fracture testing, microhardness), density measurement, SEM, general characterization (optical, video documentation).



In-cell JEOL 6010LA and fractograph from irradiated tensile specimen

LAMDA: Low Activation Materials Development and Analysis

- **Overview**


- Facility designated for the study of radiological materials by advanced characterization methods and instruments.
- 4327 Sq. Ft of clean lab space and 2732 Sq. Ft of radiological contamination area
- ~9000 specimens: fuels, metals, ceramics, graphite

- **Specimen acceptance criteria**

- 100,000 dpm/100cm² beta/gamma
- 2,000 dpm/100cm² alpha
- 100 mR/hr @ 30cm

- **Core capabilities**

- Microstructure characterization
- Thermal/physical property
- Mechanical testing
- Machining irradiated materials
- Various specialized instruments



Mechanical property testing instruments

- **Test Resource 160 series torsion test machine**
 - 125Nm torsion system
 - Adjustable speed to 8 rpm
- **Tinius Olsen Impact 104**
 - Pendulum impact tester; Charpy or Izod configuration
 - 30J capacity
 - Testing temperatures from -196 to 400°C
- **Creep test stands**
 - 1kN load capacity; Air environment
 - Temperature from -196 to 500°C
- **Buehler Wilson VH3100 microhardness tester (10 to 1000g load, programmable)**
- **Mituyoyo Vickers Microhardness (10 to 2500g load, programmable)**
- **Agilent Technologies G200 Nano Indentation system**
- **Sonic velocity measurement system**
 - Measure Young's and shear moduli with the sonic velocity methodology according to ASTM C769 and C1419




Microscopes: TEM, FIBs, and SEM

**FIB with cryo-stage:
Good for sensitive
materials (i.e., prevent
hydriding of Zr alloys)**




**FEI Quanta 3D
200i Dual Beam**

**Shielded FIB:
Control panel outside of 50 mm-thick lead
envelope. Allows high-dose samples to be milled
under ALARA conditions**



FEI Quanta 3D 200i Dual Beam



FEI Versa 3D Hi-Vac Dual Beam

**High-Brightness FEG
Electron Source**
• <1.7 nm resolution



Available Detectors:

- Secondary electrons (ETD and In-Lens)
- Retractable annular Backscattered electron detector
- Extended wavelength cathodoluminescence (CL) detector

**High-Brightness FEG
Electron Source**
• 0.96 nm resolution

Available Detectors:

- Secondary electrons (ETD and in-column)
- Backscattered electrons (ETD & concentric)
- STEM
- Secondary ions



Tescan MIRA3 GMH

- JEOL JEM 2100F Transmission Electron Microscope (FEG, TEM/STEM, EDS, EELS)
- FEI Talos F200X Transmission Electron Microscope (X-FEG, TEM/STEM, super-X EDS)
- XRADIA X-ray Tomography
- Positron Annihilation Spectroscopy

Acknowledgements

- This research work was supported by the US Department of Energy's National Nuclear Security Administration, Office of Material Management and Minimization, Molybdenum-99 Program. This manuscript has been authored by UT-Battelle, LLC, under Contract No. DE-AC05-00OR22725 with the US Department of Energy.
- Thanks to Brian Eckhart, Chris Bryan, Nesrin Cetiner
- Also thanks to Maxim Gussev, Xunxiang Hu, Christian M. Petrie, Keith J. Leonard, Kevin Field, Xiang Chen, Joshua E. Schmidlin, Chad Parish, Philip D. Edmondson, Yutai Katoh

Thank you very much for your attention.

Questions ?

Lauren Garrison
garrisonlm@ornl.gov

